



# Method for Nondestructive Evaluation of Thermal Protection System Materials and Other Materials via Ultraviolet Spectroscopy

*presented by*

**D. Elizabeth Pugel, Ph.D.** (Betsy.Pugel@nasa.gov),  
**Detector Systems Branch**  
**NASA Goddard Space Flight Center**

**SAMPE 2007**

June 6, 2007

1

## Contents




- **Technology Overview**
  - *Ultraviolet (UV) Spectroscopy Fundamentals*
  - *Description of Technology*
- **Applications**
- **Advantages**
- **Test-Bed Systems**
  - *Stardust Sample Return Capsule*
  - *Crew Exploration Vehicle (CEV)*
- **Technology Transfer**

2

# UV Spectroscopy Fundamentals



## Inorganic Compounds




Excitation of states from:  
 Valence  $\rightarrow$  Conduction Band  
 Defect  $\rightarrow$  Conduction Band

by absorbing light with  
 $E = E_{gap}$  or  $E_{defect}$

EXAMPLES: Super Light Ablator (SLA)  
 Thermal Coatings

## Organic Compounds




Excitation of states from:  
 Highest Occupied  $\rightarrow$   
 Lowest Unoccupied Molecular Orbital  
 (HOMO  $\rightarrow$  LUMO)

by absorbing light with  
 $E = E_{HOMO} - E_{LUMO}$

EXAMPLES: PICA  
 Cyanate Esters, Epoxides


3

# Description of Technology



4

## Technology Schematic



5

## Applications



- Manufacturing process development, quality control, material aging/health issues
- Space
  - Inspection of composite and resin-based structures (TPS)
- Aerospace
  - Real-time process control of a composite structure's initial curing
- Commercial Structures
  - Composite Structures: Bridges, chemical storage tanks
  - Paints and coatings
- Medical/Dental Structures
  - Determination of end-cure point of resin fillings



6


## Benefits



- **Nondestructive**
  - Materials not damaged or destroyed
- **Lightweight, highly portable**
  - *In-situ* measurement capabilities
  - Eliminates disassembly, destructively obtaining small samples for lab testing
- **Cost-effective**
  - Hardware widely used in UV imaging, spectroscopy

7

## Test-Bed System: *Stardust*



Can UV imaging and spectroscopy be used to identify:

- Structural variations?
- Chemical composition variations?

8


## SLA Backshell



**Thermal Protection System Material**  
– SLA  
*Super Light Ablator*

**Composition:**  
*Ground cork + silicon + phenolic microspheres in a silicone binder packed into a phenolic honeycomb*

**Response to Ultraviolet Light:**  
1. Organic: Phenolic resin  
2. Inorganics: Visible defect states associated with Si  
(red + blue + green → white light)




9

## SLA Backshell




### Imaging Response at Bond Line:

**Visible Illumination**  
(room lighting)



**Ultraviolet Illumination**  
( $\lambda_{Excite} = 337 \text{ nm}$ )



**UV Illumination Shows SLA Excess at Mating Surfaces of Honeycomb**

**Post-Manufacturing Inspection of Seam Variations**


10

## SLA Backshell




### Spectral Response at Bond Line:

Perform UV spectroscopy  
on and off bond line



$\lambda_{Excite} = 337 \text{ nm}$




UV Spectroscopy shows Si-based defect response

Capability to Pinpoint Source of Post-Manufacturing  
Variation

11

## Test-Bed System: Stardust



Can UV imaging/spectroscopy be used to identify:

- Structural variations?
- Chemical composition variations?

12

## Forebody Heatshield



### Thermal Protection System Material – PICA


Phenolic Impregnated Carbon  
Ablator

#### Composition:

Carbon fiber form impregnated  
with phenolic resin and cured

#### Response to Ultraviolet Light:

Organic: associated with  $\pi$   
electron transition in functional  
groups of phenolic resin



phenolic resin  
carbon fibers

13

## Forebody Heatshield



*How can we determine chemical composition  
variations across a material ?*



Conduct ultraviolet spectroscopy



14

# Forebody Heatshield



## Probe reflectance vs. length:

(chemical composition variation vs. length is a result of thermal exposure of the PICA)




15

Test-Bed Systems: Stardust


# Forebody Heatshield



Changes in spectra correspond to changes of chemical functional groups:



Condensed PAHs & singly bonded carbon (out of instrumental range)  
Increased methyl groups and loss of ethers, loss of benzenoid groups  
Dehydration of -OH on phenyl groups to form diphenyl/diphenylene ethers, hydroxybenzophenone (Biphenyl)<sub>n</sub>



16





## Test-Bed System Summary



**UV imaging/spectroscopy can be used to identify:**

- Structural variations
- Chemical composition variations



**Extended Developmental Efforts:**  
**Chemical Composition Variation**  
**Associated with Degree of Cure**

17

## Technology Transfer



**Currently seeking patent protection**

- *Licensing opportunities available*

**Partnership/Collaboration opportunities: Scale-up**

- *Development of large-scale scanners*
- *Materials database expansion*

**For more information:**

**<http://ipp.gsfc.nasa.gov/ft-tech-materials-testing.html>**

18

## Acknowledgements



- Goddard Space Flight Center's Detector Systems Branch
  - D. Elizabeth Pugel
  - S. Babu
  - P. Shu
  - C.M. Stahle
  - L.R. Miko
- Goddard Space Flight Center's Innovative Partnerships Program Office
  - N. Cheeks
  - E. Santiago-Arce
  - T. Mecum
  - D. Mitchell
  - N. Pekar
  - N. Stangle-Castor
  - L. Keesey
  - A. Proctor
- Ames Research Center's Thermal Protection Systems Branch
  - D. Kontinos
  - M. Stackpoole
  - E. Venkatapathy
  - R. Beck
  - D. Empey
  - M. Gasch
  - G. Raiche
  - J. Reuther
- Johnson Space Center's Astromaterials Research & Exploration Sciences
  - K.M. McNamara
  - C. Schwartz
  - J. Warren

19

## Method for Nondestructive Evaluation of Thermal Protection System Materials and Other Materials via Ultraviolet Spectroscopy

*presented by*

**D. Elizabeth Pugel** (Betsy.Pugel@nasa.gov)

**Detector Systems Branch**

**NASA Goddard Space Flight Center**

**SAMPE 2007**

June 6, 2007



20







## Effect of Conjugation on Absorption Peak Position




- Linear carbon chains

As the amount of conjugation (double-single bonds) increases, the peak position of the UV spectrum red shifts:

Red shifting is a consequence of the change in the electronic states (energy levels):

	165 nm
	217 nm
	256 nm
	290 nm
	334 nm
	364 nm




21

## Effect of Conjugation on Absorption Peak Position



- Benzene Rings/Polycyclic Aromatic Hydrocarbons (PAH)
  - Similar to the linear chains, when PAH present, the peak in the absorption spectrum shifts as the number of rings in the PAH increases



22